



PO Box 1135/179 Belvedere Road, Keene, NH 03431
Sales Line: 1-800-394-5889 X 301 Tech Line: 1-603-355-4955 X 302

Instruction Sheet

Part Number APG-QSDB Powerglide Quick Set, Dedenbear Case

Contents:

Quick Set Casting
Instruction Sheet

Note: Before installation, read instructions carefully. If you do not understand any part of these instructions please call our tech line at the number listed above.

Safety Warning!!

If you are unfamiliar with transmission repair and modifications, do not install this part. Instead, have it installed by a competent transmission technician who is familiar with such devices.

Failure to follow these directions and follow all safety procedures can result in serious injury or death!

Note

The purpose of the Quick Set is to reduce the volume of transmission fluid required to set the transbrake. This part is effective only when using a "double dump" pro tree transbrake.

Because of the variations in cases the Quick Set casting will need to be trimmed to fit your individual case.

Step 1:

Trim the Quick Set casting to fit the cavity in your case. Trimming can be accomplished with a utility knife, file or belt sander.

Step 2:

Trim the casting until it will fit into the cavity indicated in the figure below. (A stock case is shown in the photo, but the relative position in the Dedenbear Case is the same.)The casting must sit just below flush with the machined surface of the case.

Step 3:

Assemble transmission using the metal blocker plate (supplied with your transbrake), billet governor support, or shorty cover.

